



Unit A, Castle Industrial Park,  
Pear Tree Lane,  
Newbury,  
Berkshire.  
RG14 2EZ

Tel: (01635) 30059  
Fax: (01635) 521249

[sales@ptprofiles.co.uk](mailto:sales@ptprofiles.co.uk)  
[www.ptprofiles.co.uk](http://www.ptprofiles.co.uk)

### PT1401 Intermediate Profile

1. To fasten to the wall, push the hooked end of the clamping bolt through a joint so that it grips the rear face of a brick and locate Profile onto the bolt. Make sure that the fulcrum (A) is fully located on a brick face and not a joint.
2. Fasten with the wing nut (finger tight).
3. To adjust the plumb move the wing nut (B) in conjunction with the lower adjusting screw (C). This will move the top of the Profile in or out as required.
4. Once set, clip on the line holders (D) and run lines to other Profiles.
5. After approximately six courses push the stabilisers (E) into vertical joints adjacent to the Profile and thread the bolts (F) through until they touch the sides of the mast. **Do not over-tighten.**

**All plumbing is carried out using the setting screws.  
Do not over-tighten the screws or wing nuts.  
Keep all adjustment screws clean and lubricated.**

