


Unit A, Castle Industrial Park,  
Pear Tree Lane,  
Newbury,  
Berkshire.  
RG14 2EZ

Tel: (01635) 30059  
Fax: (01635) 521249

[sales@ptprofiles.co.uk](mailto:sales@ptprofiles.co.uk)  
[www.ptprofiles.co.uk](http://www.ptprofiles.co.uk)

### **PTP1501 Projection Equipment**

FOR USE WHEN THERE ARE PIERS PROJECTING FORWARD FROM THE MAIN WALL FACE.



- Clamp External Profile to corner as illustrated.
- Assemble equipment by placing one arm on the ground and sliding bar onto this arm, lock in approximate position required. Repeat this operation with the other arm.
- By holding the bar of this assembly, clamp the arms to the External Profile, making sure the arms themselves are on the outside face of the Profile, tighten thumb screws, fit lineholder to bar and line up to the face required, adjust for plumb and tighten thumb screws.
- The gauge will be picked up from the lines set on the External Profile.